




PARTS LIST FOR MODEL AS PURIV3000



| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION |
|---------|----------|----------------|--------------------------------|
| 1 | 1555218 | 1-PURIV3000 | Housing |
| 8 | 1308047 | 8-CFT3000 | Main Gear |
| 8A | 1191028 | 8A-3000SG | Shim (2 req) |
| 8B | 1485199 | 8B-PURIII3000 | Shim B |
| 15 | 1555219 | 15-PURIV3000 | Handle Assembly |
| 19 | 1485212 | 19-PURIII3000 | Pinion Gear |
| 19A | 1191252 | 19A-3000SG | Bushing (2 req) |
| 20A | 1308051 | 20A-CFT3000 | Ball Bearing |
| 20B | 1211610 | 20D-5000BTL | Ball Bearing |
| 20C | 1308050 | 20-CFT3000 | Ball Bearing (2 req) |
| 21 | 1308052 | 21-CFT3000 | Bearing Retainer |
| 21A | 1485211 | 21A-PURIII3000 | Bearing Retainer Screw (3 req) |
| 21B | 1192648 | 21B-3000SG | Collar |
| 24 | 1555220 | 24-PURIV3000 | Bail Wire |

| KEY NO. | PART NO. | PENN STYLE NO. | DESCRIPTION |
|---------|----------|-----------------|--------------------------------|
| 25 | 1308056 | 25-CFT3000 | Bail Holder |
| 27 | 1485210 | 27-PURIII3000 | Rotor |
| 27A | 1308059 | 27A-CFT3000 | Bail Pivot Cover |
| 28 | 1308061 | 28-CFT3000 | Trip Lever |
| 31 | 1308063 | 31-CFT3000 | Bail Arm Screw (2 req) |
| 32 | 1191586 | 32-3000SG | Bail Spring |
| 34 | 1308064 | 34-CFT3000 | Bail Arm |
| 34C | 1308065 | 34C-CFT3000 | Pivot Arm |
| 35 | 1308066 | 35-CFT3000 | Line Roller |
| 35A | 1308067 | 35A-CFT3000 | Line Roller Bushing |
| 36 | 1191699 | 36-3000SG | Bail Stud Screw |
| 38 | 1203994 | 38-3000PUR | Rotor Nut |
| 38A | 1308069 | 38A-CFT3000 | Rotor Locking Plate Screw |
| 38D | 1308070 | 38D-CFT3000 | Rotor Nut Washer |
| 39 | 1365725 | 39-FRCII3000 | Main Shaft Assembly |
| 43 | 1485219 | 43-PURIII3000 | Crosswind Block |
| 43A | 1191818 | 43A-3000SG | Crosswind Block Plate |
| 43B | 1203997 | 43B-3000PUR | Bail Pivot Cover Screw (2 req) |
| 44 | 1191843 | 44-3000SG | Crosswind Block Screw |
| 45 | 1485213 | 45-PURIII3000 | Housing Cover |
| 46 | 1485201 | 46-PURIII3000 | Housing Cover Screw (3 req) |
| 46A | 1485202 | 46A-PURIII3000 | Housing Cover Screw |
| 47 | 1555221 | 47-PURIV3000 | Spool Assembly |
| 48 | 1211604 | 48-3000SG | Click Tongue |
| 48A | 1214226 | 48A-3000SG | Click Tongue Washer |
| 48B | 1214189 | 48B-3000SG | Spool Click Screw |
| 49 | 1211605 | 49-3000SG | Click Tongue Spring |
| 51 | 1308078 | 51-CFT3000 | Drag Retaining Ring |
| 52 | 1555222 | 52-PURIV3000 | Drag Knob Assembly |
| 56 | 1485222 | 56-PURIII3000 | Drag Washer (2 req) |
| 57 | 1192043 | 57-3000SG | Keyed Washer (2 req) |
| 60 | 1192060 | 60-3000SG | Thrust Washer |
| 95B | 1308081 | 95B-CFT3000 | Rotor Locking Plate |
| 98C | 1192212 | 98C-3000SG | Clutch/Sleeve Assembly |
| 98W | 1204004 | 98W-3000PUR | Washer |
| 132 | 1192296 | 132-3000SG | Roller Washer |
| 132A | 1192302 | 132A-3000SG | Line Roller Washer (2 req) |
| 226 | 1485215 | 226-PURIII3000 | Rear Cover |
| 226A | 1485216 | 226A-PURIII3000 | Rear Cover Screw |
| 231 | 1485217 | 231-PURIII3000 | Crosswind Gear |
| 231B | 1485218 | 231B-PURIII3000 | Screw Crosswind Gear |
| 233 | 1529387 | 233-BTLIII3000 | Bearing Cover Assembly |

407-PURIV3000 Rev.0 2-1-2021

1545781