

## Penn Reel Parts list for Model: 116A 10/0 Senator

KEY	PART		KEY	PART	
NO	NO.	DESCRIPTION	NO	NO.	DESCRIPTION
1	1-116A	HANDLE SIDE PLATE	26	26-116	HANDLE SIDE BEARING
2	2-116-O	OUTER RING (2 REQUIRED)	27	27-116	NON-HANDLE SIDE PLATE
2A	2-116-l	INNER HANDLE SIDE RING	28	28-116-l	INNER NON-HANDLE SIDE RING
3	3-116	BRIDGE W/ SLEEVE	30	30-116A	STAND
4	4-116	FIBER WASHER	31	39-12	HANDLE SIDE STAND SCREW
5	5-116	MAIN GEAR	32	32-21	NON-HANDLE SIDE STAND SCREW
6	6-116	DRAG WASHER (7 REQUIRED)	33	33-116	ROD CLAMP
7C	7C-116	METAL DRAG WASHER SET	34	34-116	CLAMP SCREW
8	8-116	TENSION SPRING	35	35-115	CLICK TONGUE
9	9-116	SPACING SLEEVE	36	36-115	CLICK BUTTON
10	10-116	STAR DRAG WHEEL	37	37-116A	FRAME POST (8 REQUIRED)
11	11-116	ECCENTRIC JACK	38	39-13	POST SCREW, BOTH SIDES (16 REQUIRED)
12	12-116	PINION YOKE	40	26-116	NON-HANDLE SIDE BEARING
13	13-116	PINION	54	54-114	HARNESS LUG (2 REQUIRED)
14	14-116	DOG SPRING	54A	54-116	HARNESS LUG (2 REQUIRED)
15	15-116	DOG	56	56-116	ROD BRACE
16	16-114	LOWER BRIDGE SCREW (2 REQUIRED)	56C	56C-116	ROD BRACE (COMPLETE)
17	17-114	UPPER BRIDGE SCREW (2 REQUIRED)	56P *	56P-117	ROD BRACE PAD
18	18-114	CLUTCH SPRING (2 REQUIRED)	98	98-116	GEAR SLEEVE
19	19-115	ECCENTRIC	99	99-116	HOOK SCREW L.H. THREAD (2 REQUIRED)
20	20-114	ECCENTRIC SPRING	149	149-116L	HEX NUT (2 REQUIRED)
21	21-116	ECCENTRIC LEVER	149A	149-116H	CLAMP NUT (2 REQUIRED)
22	23-60	ECCENTRIC SCREW	155	155-116	TURN BUCKLE (2 REQUIRED)
23	23-116	HANDLE SCREW	165	165-116	HOOK SCREW L.H. THREAD (2 REQUIRED)
23A		HANDLE LOCK SCREW	*Not Sh		

24 24-116 HANDLE

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept. SBT Ver. 082615

\*154 154-116 Shim, Spool Shaft

## THESE OLD STYLE PARTS ARE NOT AVAILABLE:

136 136-116 Collar (old style outer access drags)

140 140-116 Felt Washer (old style outer access drags)