



## Penn Reel Parts list for Model 50T INTERNATIONAL II SPEED KEY PART KEY PART **DESCRIPTION** NO. NO NO. NO **DESCRIPTION** 2-50 38B 38-7 COUPLING PLATE SCREW (3 REQ.) 2 QUADRANT RING 4-50 **CAM THRUST WASHER** 38C 38-80 LONG QUADRANT SCREW 41-50 5 5-50 MAIN GEAR (50T) 41 L.S. BEARING SPRING 46A-704 CAM HOUSING SCREW (2 REQ) 6 6-155 SPACER WASHER 7 7-50 FLOATING DRAG WASHER 54 54-50T HARNESS LUG (2 REQ.) BALL BEARING (3 REQ.) 9 9-30 SPACING SLEEVE 55 55-50 BALL BEARING (1 REQ.) 13 13-50 **PINION GEAR** 55A 55-80 13B-50T 59-50 13B SPOOL SLEEVE 59 SLOTTED WASHER 14-50 DOG SPRING (2 REQ.) 60 60-50 **BACKING WASHER** 14 15 15-50 DOG (2 REQ.) 62 62-50 **CLICK SPRING** 18-50W DISC CLUTCH SPRING (2 REQ.) 63 63-30T 18 STAND SCREWS (4 REQ.) 18A 18-50TW DISC CLUTCH SPRING (2 REQ.) 63A 63A-50 **GEAR RETAINER SCREW** 63B 63-50 19-50W 19 **ECCENTRIC CAM** SCREW 21 21-50 **ECCENTRIC LEVER** 63C 63A-50 LONG SCREW 22 22-109 DOG SPRING SCREW 69B 69B-50 **RETAINING RING** 23 23-114 HANDLE SCREW 81 81-50 RATCHET 24 24-50T HANDLE COMPLETE 91 91N-50 HANDLE RIVET 24A 24-50-1 HANDLE BLANK ONLY 95 95-50 **CLICK TONGUE BUSHING** 24C 24C-50 95A 95A-20 HANDLE KNOB CAP CLICK BUSHING WASHER 95C 95A-50 25 25-50 HANDLE KNOB **CLICK BUSHING WASHER** 27 27-50T L.S. PLATE ASSEMBLY 98 98-50T **BRIDGE BUSHING** 29L 29L-50T SPOOL 101 101-30 RATCHET PLATE SCREW (4 REQ.) 30-50T 110 110-50 30 STAND HANDLE LOCK SCREW 31T-20 SHORT QUADRANT SCREW 110A 110A-50 HANDLE LOCKING PLATE 31 32 32-14CH **CENTER QUADRANT SCREW** 112 112-50 **ECCENTRIC LEVER KNOB** 33-114 112A 112A-50 33 ROD CLAMP **ECCENTRIC KNOB SCREW** 33R-114 113 113-50 RINGED ROD CLAMP (OPTIONAL) **ECCENTRIC LEVER CAP** 117 117DN-50 34-50T CLAMP SCREW (2 REQ.) **OUTER DRIVE PLATE ASSEMBLY** 34 34C 34C-50T ROD CLAMP SCREW W/NUT 119 119-50 COUPLING PLATE 36A 36-700 123 123-50 CLICK BUTTON NUT DRAG COVER SCREW (4REQ.) 36S 36S-80ST **CLICK BUTTON CAP** 124 124-50 **BRIDGE COVER** 38 38T-50 FRAME SCREW (9 REQ.) (38-50) 125-50 **CAM HOUSING**

38A 38-710

**CLICK BUSHING NUT** 

PAGE 2 OF 3

134	134-50	GEAR STUD	156	156-50	DRAG COVER
134A	134A-50	GEAR STUD WASHER	156A	156A-50	DRAG COVER SEAL
141	141-50	CAM FOLLOWER	157	157-50	QUADRANT SPACER BUSHING (2 REQ.)
142	142-50	CAM FOLLOWER PIN (2 REQ.)	173	173-50T	SPOOL BUSHING
143	143-50	ADJUSTING SCREW	183	183-50T	TUBE FRAME
144	144-50	PRESET KNOB	264	264-30T	STAND GASKET
152A	152A-50T	ROD CLAMP ACORN NUT (2 REQ.)	*NOT S	SHOWN	
*	154-50	SHIM, SPOOL SHAFT			

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept. SBT Ver. 082816 (Based on Penn's Rev 6 7-21-04)

	<b>OLDER DESIGN</b>			NEWER DESIGN	
1	1-50T	RIGHT SIDE PLATE ASSEMBLY	1	1-50TN	RIGHT SIDE PLATE ASSEMBLY
*	3-50	BRIDGE			(BRIDGE NOW PART OF PLATE)
35	35-50	CLICK TONGUE	35	35-50N	CLICK TONGUE
36	36-50	CLICK BUTTON	36	36N-50	CLICK BUTTON
			*	36C-50	CLICK BUTTON COMPLETE ASSEMBLY
39A	39-50	COVER SCREW (3 REQ.)	39A	39A-80S	COVER SCREW (3 REQ.)
98	98-50T	BRIDGE BUSHING	98	98-50TN	BRIDGE BUSHING

**NOTES:** Key 39A cover screws are a different length due to plate differences

The 36C-50 click button assembly can be used on the older plates

There are photos of the plates and clicker parts in the www.pennparts.com website for comparison

	OLD INDIVIDUAL PARTS:		MERGED INTO ONE UNIT:		
69	69-50	LOCATING PIN (2 REQ.)			
69B	69B-50	RETAINING RING (2 REQ.)	161C 161C-50	LOCATING PIN BUSHING ASSEMBLY (2 REQ.)	
161	161-50	LOCATING PIN BUSHING (2 REQ.)			
162	162-50	LOCATING PIN SPRING (2 REQ.)			

PAGE 3 OF 3