

Penn Reel Parts list for Model: SV6000 Silverado Series

KEY	PART		KEY	PART	
NO	NO.	DESCRIPTION	NO	NO.	DESCRIPTION
1	1-6000SV	HOUSING	38A	38A-2000CV	ROTOR NUT SCREW
8	8-5000SV	MAIN GEAR ASSEMBLY	39	39-5000SV	SPOOL SHAFT
8A	8A-5000CV	MAIN GEAR SHIM	40B	40B-5000CV	CLICK RATCHET
15	15-5000SV	HANDLE ASSEMBLY	43	43-5000SV	CROSSWIND BLOCK
19	19-5000SV	PINION GEAR	44	44-2000SV	CROSSWIND BLOCK SCREW
20	20-5000CV	BALL BEARING (3 REQ.)	45	45-6000SV	HOUSING COVER
21	21-5000SV	COLLAR	45A	45A-5000SV	LEFT SIDE REAR CAP
21A	21A-2000SV	BEARING MOUNTING SCREW (3 REQ.	45B	45B-5000SV	RIGHT SIDE REAR CAP
21B	21B-5000SV	BALL BEARING FIXED WASHER	46	46-2000CV	HOUSING COVER SCREW (3 REQ.
22	22-2000SV	BAIL ARM COVER SCREW	47	47-6000SV	SPOOL ASSEMBLY
22A	22A-2000SV	SIDE COVER SCREW	49	49-2000CV	SPOOL CLICK SPRING
22B	22B-2000SV	SIDE COVER SCREW	51	51-2000CV	RETAINING RING
24	24-6000SV	BAIL WIRE	52	52-5000SV	DRAG KNOB
27	27-6000SV	ROTOR CUP	56	56-2000CV	FRICTION DRAG WASHER (3 REQ.
27A	27A-5000SV	BAIL PIVOT COER	57	57-5000CV	KEYED WASHER (2 REQ.)
27E	27E-5000SV	BALANCE WEIGHT	58	58-2000CV	DRAG WASHER, EARRED
28	28-6000SV	TRIP LEVER	60	60-5000CV	THRUST WASHER
29	29-4000SV	SPRING	98	98-5000SV	CLUTCH RETAINER
31	31-2000CV	BAIL ARM SCREW	132	132-2000CV	ROLLER WASHER
31A	31-2000CV	BAIL WIRE SCREW	226	226-5000SV	REAR CAP
32	32-5000SV	BAIL SPRING	226A	226A-2000SV	REAR CAP SCREW
34	34-5000SV	BAIL ARM	227	227-5000SV	CAM COVER
34B	34B-5000SV	PIVOT GUIDE	231	231-5000SV	CROSSWIND GEAR
34C	34C-5000SV	PIVOT ARM	231A	231A-4000CV	CROSSWIND GEAR BEARING
35	35-4000SV	LINE ROLLER	231B	231B-5000SV	CROSSWIND GEAR SCREW
35A	35A-2000CV	LINE ROLLER BALL BEARING	233	233N-2000CV	BEARING COVER
35B	35B-4000SV	LINE ROLLER BUSHING	233A	233A-2000SV	BEARING COVER WASHER
36	36-4000SV	BAIL STUD SCREW			
38	38-5000CV	ROTOR NUT			

NOTE:Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept. SBT Ver. 111607

Design Change Notes:

The original 231-5000SV crosswind gear had a small hole to fit on the housing. The newer 231-5000SV have a larger hole that sits the 231A-4000CV bearing

SERVICE NOTES: Caution!

inner collar. The roller bearings do not stay put in the plastic bearing case without assistance.

Careful not to loose the bearings! If one drops reinstall and pack with Penn blue grease to hold in place until parts are reassembled.