



**PARTS LIST FOR
INTERNATIONAL 50W**

www.PENNparts.com

Scott's Bait & Tackle

Penn Parts Dept.
945 Radio Road
Tuckerton NJ 08087
(609) 296-1300

No Minimum Order!
Plus, Parts in stock
that Penn doesn't
carry anymore.

SBT Ver 100816

Penn Reel Parts list for Model: 50W International

KEY NO	PART NO.	DESCRIPTION	KEY NO	PART NO.	DESCRIPTION
1	1-50W	RIGHT SIDE PLATE ASSEMBLY	37	37-50W	FRAME POST
2	2-50	QUADRANT RING	37A	37A-50W	SPACER BAR
3	3-50	BRIDGE ASSEMBLY	38	38-50	POST SCREW
4	4-50	CAM THRUST WASHER	39	39-12	BRIDGE SCREW
5	5-50	MAIN GEAR	39-50	39-50	SPECIAL POST SCREW
6A	6-155	SPACER WASHER	40	55-80	LEFT SIDE BEARING
7A	7-50	SPOOL-METAL WASHER (old 7A-50)	41	41-50S	L.S. BEARING SPRING
9	9-50	SPACING SLEEVE (NOT SHOWN)	54	54-50T	HARNESS LUG
13	13-50	PINION GEAR	55	55-50	BALL BEARING (2 REQ.)
14	14-50	DOG SPRING (2 REQ.)	59	59-50	SLOTTED WASHER
15	15-50	DOG (2 REQ.)	60	60-50	BACKING WASHER
18	18-50W	DISC CLUTCH SPRING	69	69-50	LOCATING PIN
18A	95A-20	CLICK BUSHING WASHER (N/S)	69B	69B-50	RETAINING PIN
19	19-50W	ECCENTRIC CAM	81	81-50	RATCHET
21	21-50	ECCENTRIC LEVER	101	101-30	DRAG WASHER SCREW (4 REQ.)
22	22-109	DOG SPRING SCREW	110	110-50	HANDLE LOCK SCREW
23	23-114	HANDLE SCREW	110A	110A-50	HANDLE LOCKING PLATE
24	24-50T	HANDLE COMPLETE	112	112-50	ECCENTRIC LEVER KNOB
26	55-50	RIGHT SIDE BEARING	112A	112A-50	ECCENTRIC KNOB SCREW
27	27-50W	L.S. PLATE ASSEMBLY	113	113-50	ECCENTRIC LEVER CAP
29	29L-50TW	SPOOL	117D	117DN-50	DRIVE PLATE ASSEMBLY
30	30-50W	STAND	118	38-7	MAIN GEAR PLATE SCREW
31	31-50	STAND SCREW	119	119-50	MAIN GEAR PLATE
31-20	31-20	QUADRANT SCREW	123	123-50	DRAG COVER SCREWS (4 Req.)
32	32-14	CENTER QUADRANT SCREW	124	124-50	BRIDGE COVER
33	33-114	ROD CLAMP MODEL (Old# 33-50W)	134	134-50	GEAR STUD
33R	33R-114	RINGED ROD CLAMP (OPTIONAL)	134A	134A-50	GEAR STUD WASHER
34	34-50W	CLAMP STUD (2 REQ.)	138	101-30	RATCHET SCREW

141	141-50	CAM FOLLOWER	152A	152A-50T	ROD CLAMP ACORN NUT (2 REQ.) (Old #152A-50W)
142	142-50	CAM FOLLOWER PIN (2 REQ.)	156	156-50	DRAG COVER
143	143-50	ADJUSTING SCREW	157	157-50	QUADRANT SPACER BUSHING (2 REQ.)
144	144-50	PRESET KNOB	161	161-50	LOCATING PIN BUSHING
149	211-600	ROD CLAMP HEX NUT (2 REQ.)	162	162-50	LOCATING PIN SPRING

NOTE: Many of www.pennparts.com schematics include changes that were either made by Penn, or errors found and corrected by our parts dept.
SBT Version 100816

TECHNICAL NOTES

*154 154-50 Shim, Spool Shaft

**NOT SHOWN*

6	6-50	DRAG WASHER
117	117-50	DRIVE PLATE
163	101-30	DRIVE PLATE SCREW
These parts discontinued replaced by the 117DN-50 Drive Plate Assembly		

OLDER DESIGN

35	35-50	CLICK TONGUE (Old# 35/1-50)
36	36-50	CLICK BUTTON (Old# 36/1-50)
36A	36-700	CLICK BUTTON NUT
		N/A
38A	38-710	CLICK BUSHING NUT
62	62-50	CLICK SPRING
95	95-50	CLICK TONGUE BUSHING
		N/A
		N/A
		N/A

NEWER DESIGN

35	35-50N	CLICK TONGUE
36	36N-50	CLICK BUTTON
36A	36-700	CLICK BUTTON NUT
36S	36S-80ST	CLICK BUTTON CAP
38A	38-710	CLICK BUSHING NUT
62	62-50	CLICK SPRING
95	95-50	CLICK TONGUE BUSHING
95A	95A-20	CLICK BUSHING WASHER
95C	95A-50	CLICK BUSHING WASHER
**	36C-50	CLICK BUTTON COMPLETE ASSEMBLY **

NOTES: The 36C-50 click button assembly can be used on the older plates
There are photos of the plates and clicker parts in the www.pennparts.com website for comparison
Diameter changed on button and tongue