



PARTS LIST FOR MODEL  
SQUALL II 20LWLH  
REEL PART NO. 1545926

Key No.	Part No.	Penn Style No.	Description Parts List
1	1552954	1-SQLI120LWLH	Left Side Plate
2	1553052	2-SQLI120LWLH	Side Plate Ring (Smoke)
4	1488726	4-FTHI130LW	Drag Washer
5	1553058	5-SQLI120LWLH	Main Gear
6	1237037	6-TRQ40	Washer, Tab Drag (3 req)
7	1516068	7-FTHI12SD	Keyed Metal Drag Washer (2 req)
7H	1516139	7H-FTHI12SD	Heavy Metal Drag Washer
8	1188709	8-20	Spring Washer (2 req)
9	1516200	9-FTHI140SD	Spacer Sleeve
9B	1488732	9B-FTHI130LW	Retainer Ring (3 req)
9C	1488733	9C-FTHI130LW	Retainer Ring
9D	1488734	9D-FTHI130LW	Bearing Cover

Key No.	Part No.	Penn Style No.	Description Parts List
10	1488835	10-FTHI130LWLH	Star Assembly
10A	1188711	10A-20	Star Click Retainer
10B	1188710	10B-20	Star Click Washer
10C	1188712	10C-52SMAG2	Star Click Spring
11	1308745	11-SQL15LW	Eccentric Jack
12	1308746	12-SQL15LW	Yoke
12B	1526440	12B-SQL15SD	Pinion Yoke Screw (2 req)
13	1553065	13-SQLI120LWLH	Pinion
13R	1308748	13R-SQL15LW	Retainer Ring
15	1188675	15-20	Anti Reverse Dog (3 req)
18	1188688	18-FTHLW20	Pinion Yoke Spring (2 req)
18A	1188714	18A-20	Keyed Spring Washer
19	1308804	19-SQL20LWLH	Eccentric
20	1308805	20-SQL20LWLH	Eccentric Spring

Key No.	Part No.	Penn Style No.	Description Parts List
21	1526448	21-SQLI15SD	Eccentric Lever (Smoke)
21A	1553067	21A-SQLI120LW	Eccentric Pin
22	1526450	22-SQLI15SD	Eccentric Screw (Smoke)
22A	1188690	22-20	Eccentric Screw
23	1208117	23-20	Handle Screw
23A	1188717	23A-20	Handle Lock Screw
23B	1207784	23B-20	Handle Screw Washer
23L	1191283	23L-750	Screw
24	1526451	24-SQLI140SD	Handle Assembly
24A	1188715	24A-20	Handle Thrust Washer
24C	1191335	24C-66	Cap- Handle Knob
25	1240293	25-TRQ40	Handle Knob
26	1265023	26-TRQ40NLD2	Ball Bearing
26B	1488746	26B-FTHI130LW	Spool Tension Knob
26D	1125769	26D-52SMAG2	Click Spring
26F	1125768	26F-52SMAG2	Click Plate A
26G	1125772	26G-52SMAG2	Click Plate B
27	1553072	27-SQLI120LWLH	R. Side Plate Assembly
28	1553077	28-SQLI120LW	Side Plate Ring (Smoke)
29	1553083	29-SQLI120LWLH	Spool (Smoke/Gold)
29L	1553091	29L-SQLI120LWLH	Spool Assembly
33	1229936	33-113	Rod Clamp
33C	1229936	33C-TRQ40	Rod Clamp Kit
34	1182788	34-45	Screw, Rod Clamp (2 req)
35	1308758	35-SQLLW	Click Tongue
36	1308759	36-SQLLW	Click Button
39	1553143	39-SQLI1LW	Screw (7 req)
39A	1553097	39A-SQLI1LW	Screw, Thread Cutting (2 req)
40	1188661	40-20	Bearing
40A	1188663	40A-20	Ball Bearing Retainer
40B	1188662	40B-20	Felt Washer
40C	1208115	40C-52SMAG2	Washer, Metal Thrust
40D	1125771	40D-52SMAG2	Washer, Rubber Thrust
40E	1308762	40E-SQLLW	Bronze Washer
41	1308763	41-SQL15LW	Bushing
42	1188725	42-25	Worm Shaft Assembly (20)
43	1188669	43-20	Worm Shaft Bushing
46	1208119	46-20	Line Guide Assembly
47	1188672	47-20	Line Guide Pawl
48	1208120	48-20	Line Guide Nut (Gold)
50	1308773	50-SQL20LW	Worm Shield (20)
55	1308764	55-SQL15LW	Ball Bearing
58	1188730	58-25	Line Guide Post (20)
60	1188670	60-20	Worm Shaft Washer
62A	1184033	62A-310	Spring Click (2 req)
62B	1188722	62B-SQLLW	Screw
62C	1184041	62C-321LH	Click Spring Cover (2 req)
62S	1308765	62S-SQLLW	Click Pin (2 req)
63	1184052	63-500S	Click Spring Screw (2 req)
64	1188658	64-20	Idle Gear
66	1188678	66-20	Spool Gear, Click Ratchet
69A	1188659	69A-20	Retainer (4 req)
69C	1188677	69C-20	Retainer "C" Ring
91A	1277514	91A-TRQ40NLD2	Handle Knob Washer
98	1553100	98-SQLI130LWLH	Main Gear Shaft
98B	1488764	98B-FTHI130LW	IAR Bearing
98W	1516218	98W-FTHI130LW-1	Thrust Washer
98S	1488766	98S-FTHI130LW	Gear Stud Bushing
98R	1488765	98R-FTHI130LW	Ratchet
120	1184522	120-113H	O-Ring
149	1184702	149-45	Rod Clamp Nut (2 req)
149A	1184706	149-200	Hex Nut (2 req)
154	1184721	154-117	Click Button Washer
183	1553109	183-SQLI120LWLH	Frame Assembly

